

THE MASTER OF BLADE

XILDA
THE MASTER OF BLADE

ซิลด้า (Xilda) เราคือแบรนด์ผู้ผลิตและออกแบบสินค้าสำหรับใช้ในร้านตัดผม/บาร์เบอร์ ซิลด้าเริ่มต้นจากแบรนด์กรรไกรตัดซอยสำหรับช่างผมมืออาชีพเมื่อปี 2015 โดยเน้นกรรไกรตัดซอยมาตรฐานญี่ปุ่น (Japanese Quality) จนได้รับการยอมรับว่าซิลด้าคือหนึ่งในผู้เชี่ยวชาญเรื่องใบมีด 'The Master of Blade' เป็นการบ่งบอกถึงจุดยืนของแบรนด์ในการผลิตสินค้าระดับพรีเมียม และเป็นผู้เชี่ยวชาญเรื่องใบมีด ครอบคลุมทั้งกรรไกรตัดซอย ใบมีดโกน อุปกรณ์สำหรับช่างตัดผม และล่าสุดคือปัตตาเลี่ยนจากซิลด้า

ผลิตภัณฑ์จากซิลด้าทุกชิ้นเราตั้งใจผลิตและออกแบบเพื่อให้เป็นเสมือนเพื่อนคู่กายของช่างผม ผ่านการพัฒนาและเก็บข้อมูลจากผู้ใช้งานจริง และเพื่อชาวเอเชียโดยเฉพาะ ผลิตภัณฑ์ของเราสร้างสรรค์ขึ้นสำหรับมืออาชีพ คุณสามารถวางใจได้ในคุณภาพจากแบรนด์ซิลด้า

XILDA HAIR CLIPPER
'SAMURAI SERIES'

ปัตตาเลี่ยนสำหรับซิลด้าไม่แตกต่างจากดาบของซามูไรในวัฒนธรรมญี่ปุ่น การผลิตปัตตาเลี่ยน 'ซามูไร ซีรีส์' ของซิลด้า (Xilda Samurai Series) จึงไม่แตกต่างจากการสร้างสรรค์ดาบในวัฒนธรรมซามูไรของญี่ปุ่นนั่นเอง

Samurai หรือ 'ซามูไร' หากอ่านกันตรงตัวในภาษาญี่ปุ่นหมายถึง 'นักรบ' เฟืองฟูในญี่ปุ่นหลังศตวรรษที่ 11 ในยุคนั้นผู้ที่จะมาเป็นซามูไร ต่างได้รับการคาดหวังว่าจะต้องเป็นผู้ที่มีวัฒนธรรมและอ่านออกเขียนได้ พวกเขาต้องสามารถใช้ชีวิตให้กลมกลืนไปกับคำกล่าวโบราณที่ว่า 'บุง-บุ-เรียว-โดะ' หมายถึง สว่าง, ศิลปะอักษร, ศิลปะการทหาร, วิถีทั้งสอง หรือหมายถึง 'ความกลมกลืนแห่งพู่กันและดาบ' ให้ได้ เห็นได้จากชื่อเฉพาะที่ใช้เรียกเหล่านักรบในช่วงแรกๆ เช่น 'อุรุวะชิ' คำนี้ถูกเขียนขึ้นมาด้วยตัวอักษรคันจิ ที่ผสมระหว่างลักษณะเฉพาะตัวของศิลปะอักษรญี่ปุ่น 文 ซึ่งตรงกับภาษาจีนว่า 'บุ่น' และศิลปะการทหารในภาษาญี่ปุ่นเขียนว่า 武 bu ซึ่งตรงกับภาษาจีน 'บู๊' เข้าด้วยกัน ผู้ที่จะเป็นซามูไรและครอบครองดาบซามูไรได้นั้น จึงต้องเป็นคนที่ครบเครื่องในหลากหลายด้าน ดาบซามูไรจึงเป็นตัวแทนความเชี่ยวชาญของซามูไรแต่ละคน

การตีเหล็กเพื่อทำดาบซามูไร

ความสามารถในการตีเหล็กของคนญี่ปุ่นซึ่งรับช่วงต่อมาจากจีนและเกาหลีเมื่อกว่า 1,300 ปีที่แล้ว พัฒนาจนกลายมาเป็นเอกลักษณ์ประจำชาติของตน 'อะมะกุนิ' ช่างตีดาบยุคแรกของญี่ปุ่นได้พัฒนาการตีดาบไม่ให้หักง่ายด้วยการใช้เหล็ก โดยศึกษาวิธีทำให้เหล็กแข็งแกร่งกว่าเดิม

เหล็กที่ดีของญี่ปุ่นได้จากการถลุงเรียกว่า 'ทามาฮากาเนะ' (Tamahagane) อะมะกุนิพบว่าการที่จะให้ได้ดาบคุณภาพดีต้องควบคุมของสามสิ่ง คือ ควบคุมความเย็น ควบคุมปริมาณคาร์บอน และเอาสิ่งปะปนในเหล็กออก ปริมาณคาร์บอนคือหัวใจสำคัญในการตีดาบ หากใส่คาร์บอนในเหล็กมากไปเหล็กจะเปราะ ใส่น้อยไปเหล็กจะอ่อน จึงต้องใส่ในปริมาณที่พอเหมาะ เหล็กถูกนำมาหักแบ่งเป็นชิ้นเล็กๆ วางซ้อนกันก่อนหลอม และนำไปตีให้เป็นเนื้อเดียวกัน หลังจากนั้นจึงพับเหล็กเป็นสองชั้นขณะยังร้อน แล้วตีซ้ำครั้งแล้วครั้งเล่า เหล็กจะซ้อนกันเป็นชั้นๆ เป็นหมื่นๆ ชั้น ทำให้คาร์บอนกระจายไปจนทั่วเนื้อเหล็ก แล้วจึงนำไปตีแผ่ออกให้เป็นใบดาบ จึงจะได้ใบมีดดาบที่ดี แกร่ง บาง และคม ไม่แตกต่างจากใบมีดที่เราใช้ในปัตตาเลี่ยนของ ซิลด้า ซามูไร ซีรีส์

เช็คข้อมูลเพิ่มเติมได้ที่ www.xilda.com

รุ่นต่างๆ ของ XILDA HAIR CLIPPER 'SAMURAI SERIES'

ชื่อแต่ละรุ่นของปัตตาเลี่ยนจากซิลด้า ได้มาจากชื่อขนาดของดาบซามูไรในวัฒนธรรมญี่ปุ่น



GUNTO กุนโตะ
ดาบขนาดใหญ่ มีใช้ในยุคแรกๆ ของการถือกำเนิดขึ้นของซามูไร



KEN เคน
ดาบซามูไรที่พัฒนาต่อมาจากกุนโตะ จับใช้ได้ง่ายขึ้น และมีความคมมากขึ้นกว่ากุนโตะ



KATANA คาตานะ
ดาบคู่กายของซามูไรที่สูงขึ้นมาในสมัยศตวรรษที่ 14 เป็นยุคที่เริ่มมีการบอกบรรดาศักดิ์ของซามูไรโดยผ่านดาบ



TANTO ตันโตะ
ดาบขนาดเล็ก มักนิยมพกเป็นมีดซ่อนอยู่ในเสื้อผ้า



WAKI วากิ
ชื่อเต็มคือ 'วากิคุชิ' ดาบขนาดเล็ก ใช้พกคู่กันกับดาบคาตานะ



AIKUCHI ไอคุชิ
มีดพกขนาดเล็กที่สุดในลำดับขั้นของดาบซามูไร นิยมตกแต่งให้สวยงาม และทำจากวัสดุที่มีค่า มักมอบให้กันเป็นของกำนัล

ใบรับประกันผลิตภัณฑ์ของซิลด้า

ผลิตภัณฑ์ที่ซื้อในประเทศไทย

ผลิตภัณฑ์ภายใต้แบรนด์ 'ซิลด้า' ได้รับการออกแบบและผ่านกรรมวิธีการผลิตตามมาตรฐานสูงสุดเพื่อประสิทธิภาพการใช้งานที่ดีเยี่ยม และเพื่อประโยชน์สูงสุดของการใช้งาน ขอแนะนำให้ท่านศึกษาคู่มือการใช้งาน หรืออ่านข้อมูลบนหน้าเว็บไซต์โฮมเพจฝ่ายสนับสนุนโดยละเอียด กรณีที่ผลิตภัณฑ์ทำงานผิดปกติก่อนสิ้นสุดระยะรับประกัน ซึ่งนับว่ามีโอกาสเกิดขึ้นน้อยมาก กระนั้นผลิตภัณฑ์ของซิลด้าก็ได้เตรียมบริการด้านการรับประกันไว้เป็นอย่างดี เพื่อให้ผลิตภัณฑ์ของคุณสามารถใช้งานได้อย่างสบายใจ

ซิลด้ายินดีให้บริการดูแลผลิตภัณฑ์เพื่อผู้บริโภคทุกเครื่องที่มีการใช้งานตามเงื่อนไขการรับประกันตามประเทศที่ผู้ซื้อได้ซื้อผลิตภัณฑ์นั้นๆ เพื่อประโยชน์ของคุณ กรุณายืนยันประเทศที่ระบุบนเอกสารฉบับนี้ว่าข้อมูลตรงกับประเทศที่คุณซื้อผลิตภัณฑ์หรือไม่ หากไม่ตรงกัน กรุณาเลือกประเทศที่คุณซื้อผลิตภัณฑ์เพื่อเลือกผลิตภัณฑ์ สิทธิโดยชอบด้วยกฎหมายของคุณจะไม่ถูกลิดรอนสิทธิด้วยเงื่อนไขการรับประกันผลิตภัณฑ์ระหว่างประเทศของซิลด้า

เงื่อนไขการรับประกัน การเริ่มต้นวันรับประกันเริ่มนับตั้งแต่วันที่ซื้อผลิตภัณฑ์ที่ระบุในหลักฐานการซื้อผลิตภัณฑ์ของคุณ และสิ้นสุดระยะรับประกันตามระยะเวลาที่ระบุ กรุณาเข้าไปกรอกข้อมูลของคุณและผลิตภัณฑ์ก่อนเริ่มการใช้งานที่ www.xilda.com

กรณีที่ใบรับประกันผลิตภัณฑ์สูญหาย

กรุณาแจ้งความต่อเจ้าหน้าที่ตำรวจ และใช้ใบบันทึกประจำวันของเจ้าหน้าที่ตำรวจเสมือนเป็นใบรับประกัน โดยในบันทึกประจำวัน ควรระบุชื่อของคุณ วันและสถานที่ที่ซื้อ และรุ่นของผลิตภัณฑ์ให้ชัดเจนครบถ้วน กรณีผลิตภัณฑ์มีข้อบกพร่องเนื่องจากวัสดุ และ/หรือการประกอบชิ้นส่วน ซึ่งเกิดขึ้นในระยะรับประกัน และตรวจสอบพบว่าไม่ผิดเงื่อนไข ซิลด้าจะดำเนินการแก้ไขให้โดยไม่มีค่าใช้จ่าย หากไม่สามารถซ่อมแซมแก้ไขได้ หรือมีค่าใช้จ่ายในการแก้ไขสูงเกินเกณฑ์ที่กำหนด ทางซิลด้าอาจเปลี่ยนผลิตภัณฑ์ใหม่ โดยซิลด้าขอสงวนสิทธิ์การเปลี่ยนผลิตภัณฑ์ใหม่ให้แก่คุณ โดยยึดระยะเวลาการรับประกันนับตามวันที่เริ่มซื้อผลิตภัณฑ์เครื่องเดิม

เงื่อนไขการรับประกันของซิลด้าจะมีผลคุ้มครองในกรณีที่ผู้ซื้อใช้ผลิตภัณฑ์อย่างถูกต้อง เป็นไปตามคำแนะนำการใช้งานในคู่มือการใช้ผลิตภัณฑ์ที่ระบุไว้

การไม่รับประกัน

1. การใช้ผลิตภัณฑ์ผิดประเภท รวมถึงการใช้งานนอกเหนือจากการใช้งานที่ระบุไว้ในคู่มือ
2. การละเลยหรือไม่ปฏิบัติตามคำแนะนำที่ระบุไว้ในคู่มือการใช้งาน
3. ความเสียหายใดๆ อันเกิดจากภัยธรรมชาติ หรือสภาวการณ์ผิดปกติ เช่น น้ำท่วม ฟ้าผ่า ไฟไหม้ แผ่นดินไหว ปัญหาการขนส่ง ปัญหากระแสไฟฟ้า
4. การแก้ไขหรือเปลี่ยนแปลงใดๆ โดยบุคคลหรือศูนย์บริการที่ไม่ได้รับการแต่งตั้งอย่างเป็นทางการจากซิลด้า
5. อุปกรณ์เสริม/อะไหล่ ซึ่งเสื่อมสภาพตามระยะการใช้งานปกติ เช่น แบตเตอรี่ ใบมีด สายพาน ถุงเก็บฝุ่น แผ่นกรอง รวมถึงอุปกรณ์เสริมภายนอกอื่นๆ /อะไหล่
6. เพื่อหลีกเลี่ยงความผิดพลาดที่อาจเกิดขึ้น ขอแนะนำให้คุณอ่านคู่มือการใช้งานโดยละเอียด หรือปรึกษาโฮมเพจฝ่ายสนับสนุนสำหรับการบริการเพิ่มเติม ก่อนที่จะติดต่อซิลด้าหรือตัวแทนจำหน่าย หากคุณต้องการรับบริการในระยะรับประกัน กรุณาติดต่อศูนย์บริการผลิตภัณฑ์เพื่อผู้บริโภคของฟิลิปส์ สามารถติดตามรายละเอียดได้จากเว็บไซต์ www.xilda.com ในกรณีที่ผลิตภัณฑ์พ้นระยะรับประกัน คุณสามารถติดต่อตัวแทนจำหน่ายที่คุณซื้อผลิตภัณฑ์ได้โดยตรง เพื่อความสะดวกรวดเร็วในการติดต่อ กรุณาเตรียมเอกสารดังต่อไปนี้
7. หลักฐานการซื้อผลิตภัณฑ์ของคุณ เช่น ใบเรียกเก็บเงิน หรือใบเสร็จรับเงิน ที่ระบุวันที่ซื้อ ชื่อร้านค้า ผู้จำหน่าย และหมายเลขรุ่นของผลิตภัณฑ์

ระยะการรับประกันมาตรฐาน (เฉพาะรุ่น Waki และ Aikuchi)

12 เดือน ข้อยกเว้นการรับประกันมาตรฐาน ตามกลุ่มผลิตภัณฑ์ กลุ่มผลิตภัณฑ์ ระยะการรับประกัน

เมื่อท่านซื้อผลิตภัณฑ์ของเราแล้ว กรุณาเข้าไปลงทะเบียนเพื่อรับสิทธิการรับประกันสินค้าได้ที่ www.xilda.com

คำแนะนำการใช้งาน

XILDA HAIR CLIPPER ‘SAMURAI SERIES’

ข้อมูลสำคัญ

เพื่อความปลอดภัยของคุณ โปรดทำตามคำแนะนำต่อไปนี้เมื่อใช้อุปกรณ์ไฟฟ้า
(โปรดอ่านคำแนะนำการใช้งานทั้งหมดก่อนที่จะใช้อุปกรณ์นี้)

1. โปรดใช้อุปกรณ์นี้เพื่อการตัดผมเท่านั้น
2. กรุณาตรวจสอบค่าแรงดันไฟฟ้าเมื่อต่ออุปกรณ์นี้กับแรงดันกระแสไฟฟ้าสลับ
3. ห้ามสัมผัสอุปกรณ์ด้วยมือเปียกน้ำ ขณะที่อุปกรณ์ยังเสียบปลั๊กอยู่
4. เพื่อความปลอดภัย ให้ถอดสายไฟออกทุกครั้งเมื่อใช้งานเสร็จ
5. ห้ามใช้ในอ่างอาบน้ำหรือขณะอาบน้ำด้วยฝักบัว
6. จัดเก็บในที่ที่ปลอดภัยและไม่มีโอกาสหล่นลงน้ำ ระวังอย่าให้สัมผัสถูกน้ำและของเหลวอื่น
7. ให้ใช้อุปกรณ์นี้ในสถานที่ที่ไม่เปียกชื้น
8. ถอดสายไฟออกก่อนทำความสะอาดทุกครั้ง สำหรับรุ่นไร้สาย กรุณาปิดเครื่องและถอดสายไฟ
9. หม้อแปลงไฟฟ้า ถอดสายไฟออกจากแหล่งจ่ายไฟ ก่อนทำความสะอาดอุปกรณ์
10. อย่าวางไว้ในสถานที่ที่อาจก่อให้เกิดอันตรายต่อเด็กหรือผู้พิการได้
11. ควรใช้อุปกรณ์ของคุณอย่างถูกต้องตามการใช้งานที่ถูกออกแบบมาเท่านั้น
12. ใช้อุปกรณ์เสริมที่ได้รับการแนะนำจากผู้ผลิตเท่านั้น
13. ห้ามใช้หากสายไฟเกิดชำรุด หากอุปกรณ์ทำงานผิดปกติเกิดความเสียหายหรือหล่นลงน้ำ
14. ให้ส่งอุปกรณ์ไปที่ศูนย์บริการเพื่อตรวจเช็กและซ่อมบำรุง
15. ห้ามถืออุปกรณ์โดยถือเฉพาะบริเวณสายไฟ
16. เก็บสายไฟให้ห่างจากพื้นผิวที่ร้อน
17. เมื่อจัดเก็บสายไฟ ควรตรวจดูให้แน่ใจว่าสายไฟไม่บิดหรืองอ หรือมีความเสี่ยงที่จะเกิดการขาดหรือชำรุดได้ง่าย เพื่อป้องกันอุบัติเหตุที่อาจเกิดขึ้น
18. ห้ามสอดอุปกรณ์ใดๆ เข้าไปในช่องเปิดหรือรูต่างๆ บนซิลด้าของคุณ
19. ห้ามใช้ซิลด้าเมื่อมีการใช้กระป๋องฉีดสเปรย์หรือมีการปล่อยก๊าซออกซิเจนในบริเวณใกล้เคียง เพื่อป้องกันการเกิดประกายไฟ
20. เพื่อป้องกันการบาดเจ็บที่อาจเกิดขึ้น ห้ามใช้ซิลด้าเมื่อชุดใบมีดเกิดความเสียหาย
21. คุณสามารถยืดอายุการใช้งานและเพิ่มประสิทธิภาพของใบมีดได้ด้วยการใช้น้ำมันซโลมบริเวณที่ตัดผมบ่อยๆ ให้ใช้น้ำมันสำหรับชุดตัดผมที่มาพร้อมกับผลิตภัณฑ์ หรือใช้น้ำมันของซิลด้า
22. หากชุดใบมีดมีประสิทธิภาพการทำงานด้อยลงภายหลังการใช้งานเป็นเวลานาน แม้ว่าจะได้ทำความสะอาดและซโลมน้ำมันโดยสม่ำเสมอแล้วก็ตาม คุณควรเปลี่ยนชุดใบมีดตัดผม
23. ควรใช้ฝาครอบใบมีดเสมอเมื่อไม่ได้ใช้งาน

การใช้งานปัตตาเลี่ยนในโหมดการทำงานแบบ ไร้สาย/เสียบสาย (เฉพาะรุ่น Waki และ Aikuchi)
ผลิตภัณฑ์ของซิลด้าสามารถใช้งานแบบไร้สายได้ เมื่อชาร์จแบตเตอรี่เต็ม หากพลังงานแบตเตอรี่ต่ำ คุณสามารถต่อสายจากอะแดปเตอร์เข้ากับแหล่งจ่ายไฟฟ้ากระแสสลับเพื่อการใช้งานที่ต่อเนื่อง
การชาร์จแบตเตอรี่ สำหรับรุ่นไร้สาย (เฉพาะรุ่น Waki และ Aikuchi)

1. ควรชาร์จไฟแบตเตอรี่ 3-4 ชั่วโมง ก่อนเริ่มใช้งานครั้งแรก
2. ต่อหม้อแปลงไฟฟ้าเข้ากับแหล่งจ่ายไฟฟ้ากระแสสลับ 220-240V ก่อน แล้วจึงต่อสายไฟอีกด้านเข้ากับปัตตาเลี่ยน
3. ขณะชาร์จไฟ สถานะที่ปัตตาเลี่ยนจะสว่างค้างเป็นสีน้ำเงิน และเมื่อชาร์จไฟเต็ม ไฟสถานะที่ตัวปัตตาเลี่ยนจะกะพริบเป็นสีน้ำเงิน
4. หากไม่ได้ใช้งานปัตตาเลี่ยนมากกว่า 6 เดือน ควรชาร์จแบตเตอรี่ 3-4 ชั่วโมงก่อนการใช้งาน เพื่อประสิทธิภาพสูงสุด

ข้อมูลผลิตภัณฑ์ สำหรับรุ่นมีสาย

XILDA HAIR CLIPPER ‘SAMURAI SERIES’

สำหรับรุ่นมีสาย ซิลด้ามีปัตตาเลี่ยนแบบมีสายทั้งหมด 4 รุ่นด้วยกัน ได้แก่
รุ่น Gunto
รุ่น Ken
รุ่น Katana
รุ่น Tanto

ตารางข้อมูล XILDA HAIR CLIPPER ‘SAMURAI SERIES’ รุ่นมีสาย

รายละเอียด	GUNTO	KEN	KATANA	TANTO
กระแสไฟเข้า	220-230 โวลต์ ความถี่ 50 เฮิรตซ์	220-230 โวลต์ ความถี่ 50 เฮิรตซ์	220-230 โวลต์ ความถี่ 50 เฮิรตซ์	100-240 โวลต์ ความถี่ 50 เฮิรตซ์
มอเตอร์	Pivot	Magnetic	Magnetic	Rotary
ฟันรอง	4 ชิ้น 1.5 มม./ 3 มม./6 มม./ 10 มม.	4 ชิ้น 1.5 มม./ 3 มม./6 มม./ 10 มม.	8 ชิ้น 1.5 มม./ 3 มม./4.5 มม./ 6 มม./10 มม./ 13 มม./19 มม./ 25 มม.	3 ชิ้น 1.5 มม./ 3 มม./4.5 มม.
Cutting Range	0.6-2 มม.	0.5-1.8 มม.	0.4-1.5 มม.	0.3 มม.
ความยาวสายไฟ	4 เมตร	4 เมตร	4 เมตร	4 เมตร
น้ำหนัก	389 กรัม	457 กรัม	457 กรัม	180 กรัม

ข้อมูลผลิตภัณฑ์ สำหรับรุ่นไร้สาย

XILDA HAIR CLIPPER ‘SAMURAI SERIES’

สำหรับรุ่นไร้สาย ซิลด้ามีปัตตาเลี่ยนแบบไร้สายทั้งหมด 2 รุ่นด้วยกัน ได้แก่
รุ่น Waki
รุ่น Aikuchi

ตารางข้อมูล XILDA HAIR CLIPPER ‘SAMURAI SERIES’ รุ่นไร้สาย

รายละเอียด	WAKI	AIKUCHI
กระแสไฟเข้า	100-240 โวลต์ ความถี่ 50/60 เฮิรตซ์	100-240 โวลต์ ความถี่ 50/60 เฮิรตซ์
แบตเตอรี่	Li-ion, กำลังไฟ 9.0 โวลต์ ความจุ 3250 มิลลิแอมป์	LiFePo4, กำลังไฟ 4.0 โวลต์ ความจุ 1400 มิลลิแอมป์
มอเตอร์	Rotary	Rotary
ฟันรอง	8 ชิ้น 1.5 มม./3 มม./4.5 มม./ 6 มม./10 มม./13 มม./ 19 มม./25 มม.	4 ชิ้น 1.5 มม./3 มม./6 มม./ 10 มม.
น้ำหนัก	260 กรัม ไม่รวมใบมีด	123 กรัม ไม่รวมใบมีด

รายละเอียด	WAKI	AIKUCHI
Cutting Range	0.4-1.5 มม.	0.3 มม.

การใช้ปัตตาเลี่ยนซิลด้าครั้งแรก (สำหรับทุกรุ่น)

1



ชโลมน้ำมันบริเวณใบมีด

2



เสียบปลั๊กไฟและกดสวิตช์ เปิด/ปิด
เพื่อเริ่มการทำงาน (รูป 2a) หลังจากใช้งาน
เสร็จ โยกสวิตช์เพื่อปิดการทำงาน
(รูป 2b)
หมายเหตุ: เสียงคลิกเมื่อเปิดสวิตช์อุปกรณ์
เครื่องที่ร้อนขึ้นเล็กน้อย และการสั่นในระหว่าง
การใช้งาน ถือเป็นอาการปกติ

3



เลื่อนคันโยกขึ้น (รูป 3a) เพื่อให้ได้ตำแหน่ง
ใบมีดที่เหมาะสมกับระดับความยาวในการ
ตัดผมที่สั้นที่สุด
เลื่อนคันโยกลง (รูป 3b) เพื่อให้ได้ตำแหน่ง
ใบมีดที่เหมาะกับระดับความยาวในการตัดผม
ที่ยาวที่สุด

4



การตัดผมด้วยหวีรอง
(ขึ้นอยู่กับรุ่นของอุปกรณ์)
ปัตตาเลี่ยนซิลด้าสามารถใช้งานโดยใช้หวีรอง
หรือไม่ใช้หวีรองก็ได้ ขึ้นอยู่กับทรงผมที่คุณ
ต้องการ หากต้องการใช้หวีรองให้ขยับปุ่ม
ปรับขึ้น (รูป 4a) โดยในชุดอุปกรณ์จะมี
หวีรองเบอร์ต่างๆ
(จำนวนหวีรองขึ้นกับรุ่นของแต่ละอุปกรณ์)

5



การถอดประกอบหวีรอง
นำหวีรองมาแนบไว้ที่ปลายใบมีดตัดผม
กดหวีรองเข้ากับชุดที่ตัดผมจนกว่าจะได้ยิน
เสียงคลิก (รูป 5a) การถอดหวีรอง
ทำได้ง่ายๆ ด้วยการยกขอเกี่ยวขึ้นตาม
ตำแหน่ง (รูป 5b)

คุณสามารถสั่งซื้อหวีรองเพิ่มเติมได้ที่ www.xilda.com หรือตัวแทนจำหน่ายของซิลด้าทั่วประเทศ

วิธีการดูแลรักษา

1. ห้ามจุ่มอุปกรณ์ลงในน้ำโดยเด็ดขาด
2. หลังจากใช้งานเสร็จ ให้ถอดหวีรองออกจากชุดที่ตัดผม ก่อนใช้แปรงปัดทำความสะอาด
3. ใช้ผ้านุ่มหรือผ้าเปียกหมาดๆ เช็ดทำความสะอาดอุปกรณ์เท่านั้น ห้ามใช้ผ้าเปียกน้ำจนโชก มาทำความสะอาดซิลด้าของคุณเป็นอันขาด
4. ห้ามใช้สารทำละลายหรือสารขัดเงา
5. ห้ามใช้น้ำยาทำความสะอาดอื่นๆ
6. เพื่อยืดอายุการใช้งาน และเพิ่มประสิทธิภาพของใบมีดตัดผม ควรใช้น้ำมันชโลมบริเวณที่ตัดผมบ่อยๆ แนะนำให้ใช้น้ำมันสำหรับชุดตัดผมที่มาในกล่อง
7. หากชุดใบมีดตัดผมมีประสิทธิภาพการทำงานด้อยลงภายหลังการใช้งานเป็นเวลานาน แม้จะทำความสะอาดและชโลมน้ำมันโดยสม่ำเสมอแล้วก็ตาม คุณควรเปลี่ยนชุดใบมีดตัดผมใหม่ คุณสามารถสั่งซื้อหวีรองเพิ่มเติมได้ที่ www.xilda.com หรือตัวแทนจำหน่ายของซิลด้าทั่วประเทศ
8. ควรใช้ฝาครอบใบมีดเสมอเมื่อไม่ได้ใช้งาน และเก็บไว้ในที่ที่เหมาะสม เช่น ควรเก็บไว้ห่างจากมือเด็ก และไม่อยู่ในสภาพแวดล้อมที่มีความชื้นสูง

ข้อมูลเพิ่มเติมได้ที่ www.xilda.com

XILDA

ENGLISH

XILDA
THE MASTER OF BLADE

Xilda, we are the manufacturer and designer of barber's shop / hairdresser products. Xilda started making products of hair slicing and cutting scissors for professional hairdressers in the year 2015, by focusing on Japanese Quality hair slicing cutting scissors. And it has been recognized that Xilda is one of the cutting blade specialists. The Master of Blade is the definition of our brand's positioning in making premium products and in being an expert of blade products covering slicing scissors, razors, barber accessories and our last product, hair clippers from Xilda.

All of our products are manufactured and designed to be like the buddy of hairdressers. We have developed and collected user's data from actual users and all of our products are made particularly for Asian users. Our products are made for professionals, you can trust in the quality of our brand Xilda.

XILDA HAIR CLIPPER
'SAMURAI SERIES'

Xilda hair clipper is not different from the Samurai sword found in Japanese culture and the production of hair clipper for the Xilda Samurai Series is not different from the production of swords in Samurai culture of Japan as well.

Samurai, if read in Japanese, it refers to warrior nobility that were booming in Japan after the 11th century. In that era, people becoming a samurai will be expected to be civilized and literate person. They must live in harmony with, as so called in ancient words saying 'Bung-Bu-Ryo-Do' which means Bright, Literary Art, Military Art, and Both Ways or 'the harmony of the brush and the sword' This can be seen from the specific names used in the era by warriors in the early period, such as 'Uruwashi' This word is written in kanji character which is a combination of the uniqueness of Japanese artistry character '**文** bun', which corresponds to Chinese word pronounced as 'bun', and the words 'military arts' are written in Japanese as **武** bu which corresponds to Chinese character pronounced 'bu' meaning to 'fight'. Those who are samurai warriors and have possession of the samurai sword must be a complete man in many ways. Samurai sword therefore represents the expertise of each samurai warrior.

Forging The Iron To Make A Samurai Sword

Forging process to make sword from iron not to be broken easily studying how to make steel stronger.

Best steel of Japan made from smelting called 'Tamahagane'. Amakuni found that in obtaining a good sword, it requires to control three things: Coldness, the amount of carbon, removal of impurities from the iron. The amount of carbon is a key factor in making the sword. If carbon is too much, the iron becomes fragile. If less, the iron becomes softer, thus proper amount of carbon to be filled is required. The iron is broken into small pieces and stacked as

layers before melting and forging to become homogeneous composition. Then the final iron, while still hot is folded from few layers to many ten thousand of layers causing the carbon to spread throughout the grain of the iron and then forge it to make the blade till becoming sharp sword blade that is strong, thin and sharp, not much different from the blade that we use in Xilda product in Samurai Series. For more information, visit www.xilda.com

Models of XILDA HAIR CLIPPER 'SAMURAI SERIES'

Various Models of Xilda hair clippers come from the names of size of the samurai sword in Japanese culture.



GUNTO
A large sword, used in the early age of the origin of the Samurai.



KEN
Samurai Sword developed from Gunto sword. Easy to grip, with more sharp than the Gunto.



KATANA
The buddy sword of a samurai in the 14th century, the beginning era that the rank of the samurai is represented through the type of sword..



TANTO
Small sword, often used as a knife hidden in the clothing.



WAKI
Full name is 'Wakiguchi', carried along with the Katana sword.



AIKUCHI
The smallest pocket knife in the rank of the samurai sword decorated beautifully and made of precious materials. It is usually given as a gift.

Warranty Card For Xilda Products Purchased In Thailand

To all of our valued customers. Products under the 'Xilda' brand are designed and manufactured to the highest standards for optimum performance and for the best of application. It is advisable for you to consult with the instruction manual or visit to our home page for more details in case the product malfunctions prior to warranty period, which is very rare case. Nonetheless, Xilda products are well prepared for warranty service to ensure that you will feel comfortable in using the product.

Xilda is willing to provide consumer care service to products purchased for domestic use under warranty conditions defined for country where buyer purchases the product. For your benefit, please confirm if the country indicated on this document corresponds to the country where you purchased this product. If not, please select the right country corresponding to where you purchased this product so as to select the right product information and open or access the download of warranty. Your legal rights will not be severely impaired by Xilda's international product warranty.

Warranty terms start to be valid commencing from the date of purchase as indicated in the proof of purchase of your product and end by the date as indicated in our website please go to www.xilda.com to register befur use.

In Case of Product Warranty Card Is Lost

Please inform the police and use police blotter report as a warranty card. In the blotter, your name, date and place of purchase, and product model should be clearly indicated. In case of product defect due to material and / or assembly of parts occurs within the warranty period and such defect is found to be within warranty conditions. In such a case, Xilda shall correct the defect without cost. If the defect cannot be resolved by repairing. Or in case cost for solving exceeds the warranty criteria, Xilda may replace new product. Xilda reserves the right to replace new product to you based on warranty period commencing from the date of purchase of the original purchased product.

Xilda's warranty conditions will cover in case the buyer uses the product correctly according to the instructions as specified in product user manual.

Disclaimer of Warranty

1. Misuse of Product including uses of product other than specified in the manual.
2. Ignorance or disobeying in following the instructions provided in the user's manual.
3. Any damages caused by natural disasters or unusual circumstances such as floods, lightning, fire, earthquake, transportation problems, electricity problems.
4. Any alteration or change by person or service center that is not officially authorized by Xilda.
5. Accessories / parts damaged by normal use, such as batteries, blades, belts, dust bags, filters and other external accessories / spare parts.

6· To avoid potential errors to occur, it is recommended that you read the instruction manual carefully or consult with the Support Page for additional services before contacting Xilda or our distributors. If want to be serviced in the extent of warranty period, please contact Philips Consumer Care Center. You can follow up servicing details from this website. In case the product is out of warranty period, you can contact the distributor that you purchased the product directly. For convenience when contacting our distributor, please prepare the following documents.
7· Evidence of purchase of your product, such as a bill or receipt which indicates date of purchase, store name, and product model number.

Standard Warranty Period (only Waki and Aikuchi)

12 month standard warranty, with exemption of warranty by product group, warranty period

After you purchase our product, please register the product to obtain product warranty at (QR Code)
(require update from website) www.xilda.com

Instructions for Use

XILDA HAIR CLIPPER 'SAMURAI SERIES'

Important Information

For your safety, please follow these instructions when using electrical equipment. (Please read all instructions before using this device)
1. Please use this device for hair cutting only.
2. Please check the operating voltage when connecting this device to AC outlet.
3. Do not touch the device with wet hands while the device is connected to AC outlet.
4. For your safety, unplug the power cord when after finish using.
5. Do not use the device while in a bathtub or while showering.
6. Store the device in a safe place and do not expose to water. Avoid contacting with water and other liquids.
7. Use this device in a location that is not wet.
8. Disconnect the power cord before cleaning. For wireless models, please turn off the power and unplug the power cord before cleaning.
9. For AC adaptor, unplug the power cord before cleaning the device.
10. Do not place this device it in a location that may cause harm to children or the disabled
11. Your device should only be used according to its designed functions.
12. Use accessories as recommended only by the manufacturer.

13. Do not use in case the power cord is damaged, the device malfunctions, device is damaged or dropped into water.
14. If the device malfunctions, send the device to service center for servicing.
15. Do not hold the device by holding the cord only.
16. Keep the power cord away from hot surfaces.
17. When storing the power cord, make sure it is not twisted nor bent or it is risk of getting lacerated or damaged to prevent potential accidents.
18. Do not insert any device into the opening part or holes over your Xilda device
19. Do not use the device in the area where spray cans or aerosols are used to prevent sparking.
20. To prevent potential injuries, do not use the device when the blade unit is damaged.
21. You can extend the life of your blades and increase its efficiency by applying lubricant at hair cutting area of the device more frequently. Use only lubricant in the barber kit supplied with the product. Or use lubricant product of Xilda.
22. The efficiency of blade unit is degraded after a long period of use. Even if it is cleansed and lubricated with oil regularly, you should replace new cutting bar set.
23. Always use the blade cover when not in use.

Using hair clipper in wireless/wired mode (Waki and Aikuchi models only)

Xilda products can be used wirelessly when battery is fully charged. If the battery power is low, you can connect AC adapter to the AC power source for continuous operation.

Battery charging for wireless models (Waki and Aikuchi models only)

1. Charging should be completed 3-4 hours before first use.
2. Connect the AC adaptor to 220-240V AC power source before connecting the other end of the adaptor with the hair clipper.
3. While charging, the battery status LED lights up continuously in blue color. When fully charged the status LED will blink in blue color.
4. If the hair clipper is not used for more than 6 months, the battery should be charged for 3-4 hours before use for maximum performance.

Product Information for Wired Models
XILDA HAIR CLIPPER 'SAMURAI SERIES'

Xilda clipper product for wired model contains the following 4 model names;
Gunto model
Ken model
Katana model
Tanto model

Table of information for XILDA HAIR CLIPPER 'SAMURAI SERIES' wired models

Details	GUNTO	KEN	KATANA	TANTO
Operating Voltage	220-230 Volts 50 Hz Frequency	220-230 Volts 50 Hz Frequency	220-230 Volts 50 Hz Frequency	100-240 Volts 50 Hz Frequency
Motor Type	Pivot Motor	Magnetic	Magnetic	Rotary
Comb Attachment	4 pieces : 1.5 mm / 3 mm / 6 mm / 10 mm	4 pieces : 1.5 mm / 3 mm / 6 mm / 10 mm	8 pieces : 1.5 mm / 3 mm / 4.5 mm / 6 mm / 10 mm / 13 mm / 19 mm / 25 mm	3 pieces : 1.5 mm / 3 mm / 4.5 mm
Cutting Range	0.6-2 mm	0.5-1.8 mm	0.4-1.5 mm	0.3 mm
Power Cord Length	4 meters	4 meters	4 meters	4 meters
Weight	389 grams	457 grams	457 grams	180 grams

Product Information for Wireless Models
XILDA HAIR CLIPPER 'SAMURAI SERIES'

For wireless models, Xilda wireless hair clipper products contains the following 2 models:
Waki Model
Aikuchi Model

Information Table showing information of XILDA HAIR CLIPPER 'SAMURAI SERIES', wireless models

Details	WAKI	AIKUCHI
Operating Voltage	100-240 Volts 50/60 Hz Frequency	100-240 Volts 50/60 Hz Frequency
Battery	Li-ion, 9.0 Volts, 3250 mA.	LiFePo4, 4.0Volts, 1400 mA.
Motor Type	Rotary	Rotary

Comb Attachment	8 pieces : 1.5 mm / 3 mm / 4.5 mm / 6 mm / 10 mm / 13 mm / 19 mm / 25 mm	4 pieces : 1.5 mm / 3 mm / 6 mm / 10 mm
Weight	260 grams without blade	123 grams without blade
Cutting Range	0.4-1.5 mm	0.3 mm

FIRST TIME USE FOR HAIR CLIPPERS (ALL MODELS)

1



Apply oil on the blade

2



Plug in AC power and press on / off switch to start (Fig. 2a) operation. Turn switch off (Fig. 2b) after finish using.
NOTE: The clicking sound when turning power switch on, machine is slightly warmer and vibration during use. These are normal, not the defect.

3



Adjusting can be made by pushing the lever on the side of the device (Fig. 3). You can adjust the length of cutting during use.

4



Cutting hair using clipper comb attachment
(depending on models)
If Xilda clipper can be operated with a guide comb attachment or not depends upon hairstyle you require. If comb attachment is required, move the level (Fig. 4a) up. Different numbers of guide comb attachment are supplied in accessory kit (numbers of comb provides depends on models)

5



Assembly/disassembly of guide comb attachment.
Place comb attachment to the end of the clipper blade, snap the guide comb to cutting blade until a click is heard (Fig. 5a) Removing of comb attachment is very easy by lifting the hook (Fig. 5b) up.

You can order optional comb attachment at www.xilda.com or from dealers of Xilda nationwide.

Maintenance:
1. Do not dip the device into the water.
2. After use, remove the comb attachment from the blade set before using a brush to clean.
3. Use a soft cloth or a damp cloth only for cleaning. Do not use a wet cloth for cleaning your Xilda device.
4. Do not use solvents or polishes.
5. Do not use any other cleansers.
6. To extend the life and efficiency of the cutting blade, lubricant should be applied around the cutting unit more frequently. We recommend using lubricant oil for the clipper supplied in the box
7. If the cutter blade has degraded performance after prolonged use even being cleansed and oiled regularly. You should replace the new cutting blade. You can order additional guide comb attachment at www.xilda.com or from dealers of Xilda nationwide.
8. Always use the blade cover when not in use and keep it in a suitable place, e.g., keep it away from children's hands and high humidity environment.

visit www.xilda.com